



















## system AL

	Baterija za zamenjavo <sup>③</sup>	Integrirana baterija <sup>③</sup>	AK 10 	AK 20 	AK 30 
<b>Čas polnjenja baterije (min)<sup>④</sup></b>					
AL 101 	-	-	55 / 80	105 / 150	160 / 205
AL 300 	-	-	20 / 30	25 / 45	35 / 60
AL 500 	-	-	20 / 30	25 / 45	35 / 60
<b>Čas uporabe z enim polnjenjem baterije (do ... min)<sup>⑤</sup></b>					
 STIHL HSA 25	110	-	-	-	-
 STIHL FSA 45 (s PolyCut 2-2 nožki / z nitko)	-	20 / 12	-	-	-
 STIHL HSA 45	-	40	-	-	-
 STIHL BGA 45	-	10	-	-	-
 STIHL MSA 120 C-BQ	-	-	15	35	55
 STIHL MSA 140 C-BQ	-	-	15	35	45
 STIHL FSA 56 (s kosilno glavo na nitko)	-	-	20	40	60
 STIHL HSA 56	-	-	40	80	120
 STIHL BGA 56	-	-	10	20	30
<b>Doseg z baterijo (do ... m<sup>2</sup>)<sup>⑤</sup></b>					
 VIKING MA 235	-	-	100	200	300

 Priporočena garnitura  
 Zmanjšana moč naprave

③ Čase polnjenja baterije najdete med opisi izdelkov.  
④ Časi polnjenja v minutah do 80- / 100

⑤ Navedeni časi uporabe z enim polnjenjem baterije in dosegi so orientacijski in se lahko spremenijo glede na vrsto uporabe in rezanega materiala.